

# **Bulletin 2537-M4/USA Service Bulletin**

# **Series CPOM**

Effective: November 11, 1996







FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS AND/OR SYSTEMS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.

This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product and/or system options for further investigation by users having technical expertise. It is important that you analyze all aspects of your application and review the information concerning the product or system in the current product catalog. Due to the variety of operating conditions and applications for these products or systems, the user, through its own analysis and testing, is solely responsible for making the final selection of the products and systems and assuring that all performance, safety and warning requirements of the application are met.

The products described herein, including without limitation, product features, specifications, designs, availability and pricing, are subject to change by Parker Hannifin Corporation and its subsidiaries at any time without notice.

### Offer of Sale

The items described in this document are hereby offered for sale by Parker Hannifin Corporation, its subsidiaries or its authorized distributors. This offer and its acceptance are governed by the provisions stated in the "Offer of Sale".

© Copyright 1996, Parker Hannifin Corporation, All Rights Reserved




### Manapak Check Valves Series CPOM


### **Contents**

# Series CPOM2 1 Service Parts Information 1 Ordering Information 1 Series CPOM3 2 Ordering Information 2 Series CPOM6 2 Service Parts Information 3 Ordering Information 3 Operation 4 Trouble-Shooting 4

### **Service Parts Information**



### **Ordering Information**




O Denotes Seal Compound.


		_				50
	Poppe Option	t n		C	Seal ompound	Design Code
e					Code Description V Fluorocarbons E EPR N Nitrile	
$\dashv$	Code	Item	Part No.	Qty.	Description	
┪	DD					
٦	AA	15	002298	1	Cartridge Blank	
	BB	15	002298	1	Cartridge Blank	

SAE Bolt Kits					
Manapak & Valve Combination	Bolt Kit	Description	Qty./ Kit	Torque IN-LBS.	
D1V * Valve (Non-explosion proof)	BK209	10-24 X 1.25	4	50	
1 Manapk & D1V ** Valve	BK243	10-24 X 2.88	4	50	
2 Manapak & D1V * Valve	BK225	10-24 X 4.38	4	50	
3 Manapak & D1V ** Valve	BK244	10-24 X 6.00	4	50	
4 Manapak & D1V ★ Valve BK245 10-24 X 7.50 4 50					
Note: Bolt kits must be ordered separately.					
Metr	ic Bolt K	its			

Metric Boit Kits						
Manapak & Valve Combination	Bolt Kit	Description	Qty./ Kit	Torque NM		
D1V * Valve (Non-explosion proof)	BK375	M5-0.8 X 30	4	5.7		
1 Manapak & D1V ** Valve	BK400	M5-0.8 X 70	4	5.7		
2 Manapak & D1V ** Valve	BK405	M5-0.8 X 110	4	5.7		
3 Manapak & D1V * Valve	BK429	M5-0.8 X 150	4	5.7		
4 Manapak & D1V ** Valve TK400 M5-0.8 X 205 4 5.7						
Note: Bolt kits must be ordered s	Note: Bolt kits must be ordered separately.					

### **Service Parts Information**






50


Design

Code

OPTION BB SHOWN




## **Ordering Information**



Item	Part No.	Quantities			Description
		DD	AA	BB	·
1	1301350	1	1	1	Body
2	004856	1	1	1	Piston
3	2-014\()-9	5	5	5	0-Ring
4	679192	2	2	2	Shipping Plate
5	3-912\(\)-9	2	2	2	0-Ring
6	8HP50 ○-S	2	2	2	Plug
7	4HP50 ○-S	2	2	2	Plug
8	062050	2	2	2	End Plug
9	1301066	4	4	4	Stick Screw
10	1301260	1	1	1	Nameplate
11	062054	2	1	1	Spring
12	1701017	2	1	1	Charle Associated
13	1301917	2	l	'	Check Assembly
14	2-114\(\)-7	2	1	1	0-Ring
15	8-1140-9	4	2	2	Parbak Ring

O Denotes Seal Compound.



Code	Item	Part No.	Qty.	Description
DD				
AA	16	062047	1	Cartridge Blank
BB	16	062047	1	Cartridge Blank

SAE Bolt Kits							
Manapak/Valve Combination D3W D3 Manaplus Bolt length D3DW & Bolt length Inch							
D3 (Non-explosion proof)	*BK226	*BK80	2.25	BK98	1.63		
1 Manapak +D3	*BK61	*BK91	4.25	*BK141	3.50		
2 Manapak +D3	*BK62	*BK94	6.25	*BK142	5.50		
3 Manapak +D3	*BK63	*BK95	8.25	*BK33	7.50		

- -Bolt kits are ordered separately. -All bolts are 1/4-20 and grade 8. -Torque for all D3 bolts: 12 ft-lbs. -Size 3 Manapaks are 2.0 thick.
- \*-For 3000 PSI applications only.

Metric Bolt Kits						
Manapak/Valve Combination	D3W	D3 Manaplug w/ Extension	Bolt length	D3DW & D31VW	Bolt length MM	
D3 (Non-explosion proof)	*BK310	*BKM80	55	BKM98	40	
1 Manapak +D3	*BK311	*BKM91	105	*BKM141	90	
2 Manapak +D3	*BK312	*BKM94	169	*BKM142	140	
3 Manapak +D3	*BK313	*BKM95	219	*BKM33	190	


- -Bolt kits are ordered separately. -All bolts are M6-1 and grade 12.9, -Torque for all D3 bolts: 16.3 NM. -Size 3 Manapaks are 50.0 thick.

- \*-For 3000 PSI applications only.



cpom.pm5, dd, hh

### **Service Parts Information**



### **Ordering Information**



O Denotes Seal Compound.

Pop Opt	pet				eal pound	Design Code
	Code	Item	Part No.	Qty.	Description	Code Description
	חח	15	2-0220-7	2	0-Ring	V Fluorocarbons
	DD	16	8-0220-9	4	Parbak Ring	E EPR
		15	2-0220-7	1	0-Ring	N Nitrile
	AA	16	8-0220-9	2	Parbak Ring	
		17	010727	1	Cartridge Blank	
		15	2-1140-7	1	0-Ring	
	BB	16	8-1140-9	2	Parbak Ring	
		17	010727	1	Cartridge Blank	

Bolt Kits						
Manapak & Valve Combination	Part Number	Description	Qty. Kit	Torque to:		
D6W Valve	BK120	1/2-13 UNC X 2.50	6	80 ft-lbs.		
1 Manapak & D6VW Valve	BK121	1/2-13 UNC X 5.25	6	80 ft-lbs.		
2 Manapak & D6VW Valve	BK122	1/2-13 UNC X 8	6	80 ft-lbs.		
3 Manapak & D6VW Valve	BK123	1/2-13 UNC X 10.75	6	80 ft-lbs.		
4 Manapak & D6VW Valve	BK124	1/2-13 UNC X 13.50	6	80 ft-lbs.		
Note: Bolt kits must be ordered separately.						

### **Service Information**

### **Series CPOM**

### **Operation**

A pilot operated check valve works as a standard check valve when flow is travelling from inlet to outlet. A check valve allows flow in one direction and blocks flow in the opposite direction. When the system pressure at the check valve inlet is high enough to overcome the spring force biasing the poppet, the poppet is pushed off its seat. Flow then passes through the valve. When fluid flow attempts to enter

through the outlet, the poppet is forced on its seat and, flow through the valve is blocked. When enough pilot pressure is sensed at the pilot piston, the piston is moved and unseats the check valve poppet permitting flow from the outlet port to the inlet port. Flow can pass through the valve from outlet to inlet as long as sufficient pilot pressure is acting on the pilot piston.

### **Trouble Shooting**


Problem	Cause	Solution
No flow through the valve	Broken spring	Replace spring.
	Valve installed backwards	Reverse connection.
No reverse flow through pilot operated valve	Lack of sufficient pilot pressure or pilot ratio	Check pilot pressure, increase as necessary. Verify sufficient pilot ratio.
	Pilot piston binding	Disassemble and clean valve.
Excessive leakage through check	Pilot pressure present	Check for pilot pressure. Consider pilot ratio.
	Contamination lodged in poppet seat	Inspect and remove.
	Poppet seat O-ring seal failure	Inspect and replace seals as required.
	Pilot piston binding	Disassemble and clean valve.

cpom.pm5, dd, hh



**Parker Hannifin Corporation** Hydraulic Valve Division 520 Ternes Avenue Elyria, Ohio 44035 USA

Tel: (216) 366-5200 Fax: (216) 366-5253



11/96, 5M, PHD, Printed in the USA